

INSTALLATION PROCEDURE



1. Cut to pipe O/D marked on the flashers (this is about 20% smaller than the diameter of the pipe).




2. Slide the flashers down the pipe, using water to lubricate if needed.



3. Form and bend the metal base of the flashers to fit the roof.



4. Seal the flashers by applying urethane/silicone sealant between the flashers and the roof. Use a large slot screw driver to press the base down tightly.



5. Fasten the flashers with weather resistant fasteners to complete the seal.

SIZE CHART

Flashers Size	1	2	3	4	5	6	7	8	9
Pipe O/D inches	1/4" - 2"	3/4" - 3 1/4"	1/4" - 5"	3" - 6 1/4"	4 1/2" - 7 1/2"	5" - 9"	6" - 11"	7" - 13"	10" - 19"
Pipe O/D mm	6 - 50 mm	44 - 82 mm	6 - 127 mm	75 - 16 mm	108 - 190 mm	125 - 230 mm	150 - 280 mm	175 - 330mm	254 - 483 mm
Base O/D inches	4 3/4"	6 1/4"	7 3/4"	9 1/2"	10 1/2"	12 1/2"	14 1/2"	16 1/2"	25 1/2"
O/A Height	3"	4"	4"	5"	5"	6"	6"	6"	8"
TOP O/D	Closed	1 3/8"	Closed	2 1/2"	3 1/2"	4"	4 1/2"	5 1/2"	7 1/4"

*O/D - Outside Diameter *O/A - Over All Height

Temperature Range (Grey) -65 degrees Fahrenheit to 250 degrees Fahrenheit